

















EasyWeed® For Use On: 100% cotton Poly/cotton blends 100% polyester Leather  		
Application Instructions (Home Iron): <ul style="list-style-type: none"> • Set iron dial between Cotton and Linen • Cover design with Kraft paper or non-stick cover sheet • Place on flat, hard surface (ironing board not recommended) • Press iron with medium/firm pressure for 10-15 seconds • If areas of design lift after application, replace cover sheet and re-press for 5-10 seconds. • Peel carrier hot or cold 	Application Instructions (Heat Press): <ul style="list-style-type: none"> • Cut in reverse and weed excess material • Preheat garment for 2-3 seconds • Apply design at 305°F / 150°C • Use medium pressure for 10-15 seconds • Peel carrier hot or cold 	Laundrying: <ul style="list-style-type: none"> • Wait 24 hours before first wash • Machine wash warm or cold with mild detergent • Do not bleach or dry clean • Dry on normal dryer setting
EasyWeed® Extra For Use On: 100% cotton Poly/cotton blends 100% polyester Leather  		
Application Instructions (Home Iron): <ul style="list-style-type: none"> • Set iron dial between Cotton and Linen • Cover design with Kraft paper or non-stick cover sheet • Place on flat, hard surface (ironing board not recommended) • Press iron with medium/firm pressure for 10-15 seconds • If areas of design lift after application, replace cover sheet and re-press for 5-10 seconds. • Peel carrier hot or cold 	Application Instructions (Heat Press): <ul style="list-style-type: none"> • Cut in reverse and weed excess material • Preheat garment for 2-3 seconds • Apply design at 305°F / 150°C • Use medium pressure for 10-15 seconds • Peel carrier hot or cold 	Laundrying: <ul style="list-style-type: none"> • Wait 24 hours before first wash • Machine wash warm or cold with mild detergent • Do not bleach or dry clean • Dry on normal setting
EasyWeed® Electric For Use On: 100% cotton Poly/cotton blends 100% polyester Leather  		
Application Instructions (Home Iron): <ul style="list-style-type: none"> • Set iron dial between Cotton and Linen • Cover design with Kraft paper or non-stick cover sheet • Place on flat, hard surface (ironing board not recommended) • Press iron with medium/firm pressure for 10-15 seconds • If areas of design lift after application, replace cover sheet and re-press for 5-10 seconds. • Peel carrier hot or cold 	Application Instructions (Heat Press): <ul style="list-style-type: none"> • Cut in reverse and weed excess material • Preheat garment for 2-3 seconds • Apply design at 305°F / 150°C • Use medium pressure for 10-15 seconds • Peel carrier hot or cold 	Laundrying: <ul style="list-style-type: none"> • Wait 24 hours before first wash • Machine wash warm or cold with mild detergent • Do not bleach or dry clean • Dry on normal dryer setting
EasyWeed® Stretch (matte) For Use On: 100% cotton Poly/cotton blends 100% polyester Leather  		
Application Instructions (Home Iron): <ul style="list-style-type: none"> • Set iron dial between Cotton and Linen • Cover design with Kraft paper or non-stick cover sheet • Place on flat, hard surface (ironing board not recommended) • Press iron with firm pressure for 20 seconds • If areas of design lift after application, replace cover sheet and re-press for 5-10 seconds. • Peel carrier hot or cold 	Application Instructions (Heat Press): <ul style="list-style-type: none"> • Cut in reverse and weed excess material • Preheat garment for 2-3 seconds • Apply design at 320°F / 160°C • Use firm pressure for 20 seconds • Peel carrier hot or cold 	Laundrying: <ul style="list-style-type: none"> • Wait 24 hours before first wash • Machine wash cold with mild detergent • Do not bleach or dry clean • Dry on normal setting
EasyWeed® Sub Block For Use On: 100% cotton Poly/cotton blends 100% polyester Leather  		
Application Instructions (Home Iron): <ul style="list-style-type: none"> • Set iron dial between Cotton and Linen • Cover design with Kraft paper or non-stick cover sheet • Place on flat, hard surface (ironing board not recommended) • Press iron with medium/firm pressure for 10-15 seconds • If areas of design lift after application, replace cover sheet and re-press for 5-10 seconds. • Peel carrier hot or cold 	Application Instructions (Heat Press): <ul style="list-style-type: none"> • Cut in reverse and weed excess material • Preheat garment for 2-3 seconds • Apply design at 265°F / 130°C • Use medium pressure for 10-15 seconds • Peel carrier hot or cold 	Laundrying: <ul style="list-style-type: none"> • Wait 24 hours before first wash • Machine wash warm or cold with mild detergent • Do not bleach or dry clean • Hang item to dry
EasyWeed® Adhesive For Use On: 100% cotton Poly/cotton blends 100% polyester  		
Application Instructions (Home Iron): <ul style="list-style-type: none"> • Set iron dial between Cotton and Linen • Cover design with Kraft paper or non-stick cover sheet • Place on flat, hard surface (ironing board not recommended) • Press iron with medium/firm pressure for 10-15 seconds • If areas of design lift after application, replace cover sheet and re-press for 5-10 seconds. • Peel carrier hot 	Application Instructions (Heat Press): <ul style="list-style-type: none"> • Cut in reverse and weed excess material • Preheat garment for 2-3 seconds • Apply design at 275°F / 135°C • Use medium pressure for 5-10 seconds • Peel carrier hot • Apply top layer 	Laundrying: <ul style="list-style-type: none"> • Wait 24 hours before first wash • Machine wash warm or cold with mild detergent • Do not bleach or dry clean • Dry on normal dryer setting
EasyPatterns® For Use On: 100% cotton Poly/cotton blends 100% polyester Leather  		
Application Instructions (Home Iron): <ul style="list-style-type: none"> • Set iron dial between Cotton and Linen • Cover design with Kraft paper or non-stick cover sheet • Place on flat, hard surface (ironing board not recommended) • Press iron with medium/firm pressure for 10-15 seconds • If areas of design lift after application, replace cover sheet and re-press for 10 seconds. • Peel carrier hot or cold 	Application Instructions (Heat Press): <ul style="list-style-type: none"> • Cut design (do not mirror). weed then mask • Preheat garment for 2-3 seconds • Apply design at 305°F / 150°C • Use medium pressure for 10-15 seconds • Peel carrier hot or cold • Cover and reheat for 2-3 seconds 	Laundrying: <ul style="list-style-type: none"> • Wait 24 hours before first wash • Machine wash cold with mild detergent • Do not bleach or dry clean • Dry on normal dryer setting
EasyReflective® For Use On: 100% cotton Poly/cotton blends 100% polyester Leather Lycra®/Spandex  		
Application Instructions (Home Iron): <ul style="list-style-type: none"> • Set iron dial between Cotton and Linen • Cover design with Kraft paper or non-stick cover sheet • Place on flat, hard surface (ironing board not recommended) • Press iron with medium/firm pressure for 10-15 seconds • If areas of design lift after application, replace cover sheet and re-press for 10 seconds. • Peel carrier warm 	Application Instructions (Heat Press): <ul style="list-style-type: none"> • Cut in reverse and weed excess material • Preheat garment for 2-3 seconds • Apply design at 305°F / 150°C • Use medium pressure for 15 seconds • Peel carrier warm (wait at least 15 seconds) • Cover and reheat for 2-3 seconds 	Laundrying: <ul style="list-style-type: none"> • Wait 24 hours before first wash • Machine wash warm or cold with mild detergent • Do not bleach or dry clean • Dry on normal dryer setting